


Storage Shed

OWNER'S MANUAL / Instructions for Assembly Size 10'x 8'

Patent #416.091

Ver: 1.2



**Customer
Service Hotline**
(800) 483-4674
www.uspolymersinc.com

Your Total Solution To maintenance Free Storage Sheds.

- All Weather Durable PVC
- Won't Dent, Rust, Rot or Mildew
- Tall Walk In Shed
- Never Needs Painting
- 61" Wide Double Doors
- Easy Assembly
- High Wind Tested
- Snow Load Tested 60lbs/sqft
- Pad Lock Ready (Lock not included)
- Wooden or Cement Foundation Needed

Available Kits

- Foundation Kit Available
- Modular 2.5' Extension Kits Available
- 10'x8' Window Kits Available

Requires two people and takes about
4-5 hours for Installation.

Call us for any missing or damaged parts.
Do not return to the store.

Parts List




Note: Check all parts prior to installation.


ACCESSORIES

CODE	DESCRIPTION	QTY
B1LA	FRONT 'U' CHANNEL LEFT	1
B1RA	FRONT 'U' CHANNEL RIGHT	1
B21	SIDE 'U' CHANNEL	2
B22	SIDE 'U' CHANNEL	2
B3LA	BACK 'U' CHANNEL LEFT	1
B3RA	BACK 'U' CHANNEL RIGHT	1
CMA	MIDDLE COLUMN	7
CCA	CORNER COLUMN	4
CDLA	LEFT DOOR COLUMN	1
CDRA	RIGHT DOOR COLUMN	1
CB1A	FRONT CENTER BAND	2
CB2A	SIDE CENTER BAND SHORT	2
CB3A	CENTER BAND	4
CB4A	FRONT CROSS CENTER BAND	2
RS1LA	RS1 ROOF STRUCTURE LEFT	2
RS1RA	RS1 ROOF STRUCTURE RIGHT	2
RS2A	RS2 ROOF STRUCTURE	4
RS3LA	RS3 ROOF STRUCTURE LONG	2
RS3SA	RS3 ROOF STRUCTURE SHORT	2
RS4A	RS4 ROOF STRUCTURE	4
RS5A	RS5 ROOF STRUCTURE	4
RS6A	RS6 ROOF STRUCTURE	2
RS7A	RS7 ROOF STRUCTURE	2
RS8A	RS8 ROOF STRUCTURE SUPP LONG	4
RS9A	RS9 ROOF STRUCTURE SUPP SHORT	4
RS10A	RS10 ROOF STRUCTURE SUPPORT	2
RS11A	RS11 ROOF STRUCTURE SUPPORT SHORT	2
RS12A	RS12 ROOF STRUCTURE SUPPORT LONG	2
RS14A	SAGGING SUPPORT	12
DSH	DOOR STOPPER HORIZONTAL	1
SP▲	SIDE PANEL	12
FPL	FACIA PANEL LEFT	2
FPR	FACIA PANEL RIGHT	2
RP▲	ROOF PANEL	6
RRS	RIDGE COVER SMALL	3
DL	LEFT DOOR	1
DR	RIGHT DOOR	1


CODE	DESCRIPTION	QTY
FDCL	DOOR COLUMN FITTING LEFT	1
FDCR	DOOR COLUMN FITTING RIGHT	1
FCC	CORNER COLUMN FITTING	4
FMC	MIDDLE COLUMN FITTING	7
FCB	CENTER BAND FITTING	4
RJ	90 DEGREE JOINT	4
PPG	ROOF PLUG	80
PWS	ROOF PLUG WASHER	80
PIN	ROOF PIN	80
EPS	END PLUG SQUARE	4
S1	DIA. 4.2 x 16mm. (5/32" x 5/8")	225
S2	DIA. 4.2 x 32mm. (5/32" x 1 1/4")	8
S3	M4 x 10mm. (M5/32" x 3/8")	34
	MACHINE SCREW WITH NUT	




LEFT DOOR COLUMN (CDLA) RIGHT DOOR COLUMN (CDRA)




CORNER COLUMNS (CCA) MIDDLE COLUMNS (CMA)




ROOF STRUCTURES (RS - 1LA, 1RA, 3SA, 3LA, 8A, 9A) U-Channels (B1LA) (B1RA) (B21) (B22) (B3LA) (B3RA) (CB- 1A, 2A, 3A, 4A)




ROOF STRUCTURE (RSSA) DOOR STOPPER (DSH) (RS6A) (RS7A)




SAGGING SUPPORT (RS14A) ROOF SUPPORT (RS2A) ROOF SUPPORT (RS4A) (RS10A) (RS11A) (RS12A)




CENTER BAND FITTING (FCB) MIDDLE COLUMN FITTING (FMC)




DOOR COLUMN FITTING (FDCL) DOOR COLUMN FITTING (FDCR)



CORNER COLUMN FITTING (FCC) PVC 90 DEGREE JOINT (RJ)



ROOF PIN (PIN) ROOF PLUG WASHER (PWS)




END PLUG SQUARE (EPS) ROOF PLUG (PPG)

Tools You Will Need

Cordless Drill - Philips Head
Hammer or Rubber mallet
Carpenters Square
8' Step Ladder
Adjustable pliers
Level - 3ft.
Tape Measure
Caulk Gun
Waterproof Clear Silicon
Sealant
Hand Gloves

Exploded View



Duramax Storage Shed Limited Fifteen Year Warranty

U.S. Polymer Inc. will send a replacement part free of charge, in the event of material defects and or workmanship for a period of fifteen years from the date of purchase.

This warranty is extended only to the original purchaser. A purchase receipt or other proof of date of original purchase will be required before warranty service is rendered. In no event shall we pay the cost of flooring, labor, installation or any other costs related thereto.

This warranty only covers failures due to defects in material or workmanship which occurs during normal use and does not extend to color change arising due to normal weathering or to damage resulting from misuse or neglect, commercial use, failure to follow assembly instructions and the owner's manual (including proper anchoring of the shed), painting, forces of nature and other causes which is beyond our control.

Claims under this warranty must be made within the warranty period by calling 1-800-483-4674 or mail in a dated sales slip and clear photograph of the part to:

U.S. Polymers, Inc.
6915 Slauson Avenue
Commerce, CA 90040

We reserve the right to discontinue or change components. If a component has been discontinued or is not available,
U.S. Polymers, Inc. reserves the right to substitute a component of equal quality as may be compatible.

Limits and Exclusions

There are no express warranties except as listed above. The warrantor shall not be liable for incidental or consequential damages resulting from the use of this product, or arising out of any breach of this warranty. All express warranties are limited to the warranty period set forth above. Some states do not allow the exclusion or limitation on how long an implied warranty lasts, so the above limitations may not apply to you.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state or country to country.

A. Foundation & Base Frame

Note: It is important that these instructions are followed step by step.

DuraMax must be installed on a level wooden platform or a level concrete foundation.



Wooden platform is extra and is not included. Don't install under windy conditions.


Parts needed:

- (1) Front U channel left (B1LA)
- (1) Front U channel right (B1RA)
- (1) Back U channel left (B3LA)
- (1) Back U channel right (B3RA)
- (2) Side U channel (B21)
- (2) Side U channel (B22)
- (32) Dia. 4.2 x 16mm Screws (S1)

1. Use pressure treated 2" x 4" (5x10cm) to build a foundation structure that has an outside dimension of 96" x 127" (2438.4mm x 3225.8mm).



Lay 2"x 4" (5x10cm) Flat



2. Using exterior grade CDX 3/4" (19mm) plywood, cut and fit together the sheets to form solid plywood floor as shown. Foundation must be square and level.


3. Start with U-Channel bases (B3LA) & (B3RA) to insure a quick and accurate layout. Position all U channel bases on wood foundation. It is critical that you allow 61 1/4" (1556mm) between front bases (B1LA) and (B1RA) for door placement. Measure in all directions as shown in fig.1. Make sure the U-channel assembly is a perfect square.

Wooden Platform (Not Included)


The following are a list of lumber and sizes you will need.

Pressure Treated-Wood Studs:	Exterior Grade (CDX):
6ea 2" x 4" x 89" (50 x 88.9x 2260.6mm)	3/4 (19mm) plywood
2ea 2" x 4" x 127" (50 x 88.9x 3225.8mm)	2ea 3/4" x 48" x 96" (19 x 1219.2x 2438.4mm)
	1ea 3/4" x 31" x 96" (19x 787.4x 2438.4mm)


L-Brackets: 4ea



Foundation Structure



Plywood Floor



Left Side

Right Side


Fig.1

U-Channel Layout


4. Using a carpenters square, line up all corners. Secure base to wood foundation using (S1) screws.

Concrete foundation

4b. (Concrete foundation) Using a carpenters square, line up corners. Align U-Channel base, mark the concrete at the holes in the base and drill concrete with 1/4" (dia. 6mm) concrete bit to accept anchor bolts to a 1 3/4" (44mm) depth. Replace base and secure with 1/4" x 1 3/8" (M6 x 35mm) anchor bolts (not provided).



B. Walls & Columns



All panels are clearly marked and care should be taken to use the correct one.


Parts Needed:

- (4) Corner Column (CCA)
- (1) Left Door Column (CDLA)
- (1) Right Door Column (CDRA)
- (7) Middle Column (CMA)
- (12) Side Panels (SP↑)
- (2) Front Center Band (CB1A)
- (2) Side Center Band Short (CB2A)
- (4) Center Band (CB3A)
- (2) Front Cross Center Band (CB4A)
- (4) Center Band Fitting (FCB)




Layout all required parts near shed foundation.


1. Slide door column (CDRA) into the U-Channel Base (B1RA) on the right side of the door. Line up the pre-drilled holes on (CDRA) Column with pre-drilled holes on U-Channel Base. Secure with two (S1) screws from inside. (See blowup detail)





2. Insert the side panel (SP↑) into the groove of column (CDRA). Start at the bottom of the panel at an angle then push into place.




Always place panels into frame at an angle on top and slide in sideways and downward for easy insertion.




Make sure panels are right side up with panel shingles facing down. Check the stamped label on top of all panels.



3. Slide corner column (CCA) into side panel (SP↑) pushing the column to the side panel.



4. Working outside use (S1) screws to secure column to bases (B1RA) and (B22).



5. To stabilize the front panel attach center band (CB1A). Start with center band fitting (FCB), fix to corner column (CCA) with (S2) screws. See figures (fig.1) (fig.2) and (fig.3).





Fig.1: Use (S2) screws. Fix (FCB) fitting to (CCA). Leave it loose.

Fig.2: Use (S1) screws. Fix (CB1A) to fitting (FCB)

Fig.3: Use (S1) screw. Fix (CB1A) to (CDRA)



6. Attach center band (CB4A) to door column (CDRA) and base channel (B1RA).




Fig.1: Use (S1) screw. Fix (CB4A) to (CDRA)

Fig.2: Use (S1) screw. Fix (CB4A) to base (B1RA)








Fig.3: Fix the (EPS) at the end of (CB1A) & (CB4A).



7. Assemble the center bands (CB2A) & (CB3A) with (S3) screws with nuts. Follow Overlapping Method shown below. Make 2 sets. Do not fix the screw on the middle hole.





8. Assemble the two center bands (CB3A) with (S3) screws with nuts. Follow Overlapping Method shown below.






Overlapping Method


For Center Band, Roof structure (RS3LA) & (RS3SA).




TIP Use a hammer to align the holes.




9. Working from inside Continue connecting the 3 side panels (SP↑) and columns (CMA) in sequence along (B22 & B21) base. Use (S1) screws to fix columns to base.



10. Slide corner column (CCA) into side panel (SP↑) pushing the column to the side panel.



11. Working outside Use (S1) screws to secure column to bases (B21) and (B3RA).



12. Stabilize the side panels with center bands (CB3A) & (CB2A). Fix (FCB) fitting to corner column (CCA). See Fig.1
Follow the Fig. 2, 3, 4 & 5.





Fig.1: Use (S2) screws. Fix (FCB) fitting to (CCA). Leave it loose.




Fig.2: Use (S1) screws. Fix (CB3A) to (FCB) and (CB1A)





Fig.3: Use (S1) screws. Fix (CB3A) to (CMA) columns.




Fig.4: Fix to (CMA) with (S1) screw.








Fig.5: Use (S1) Screws. Fix (CB2A) to (FCB) fitting.



13. Working from inside Continue connecting the 4 back panels (SP↑) and columns (CMA) in sequence along (B3RA) & (B3LA) base to corner column (CCA). Use (S1) screws to fix columns to base. Slide corner column (CCA) into side panel (SP↑) pushing the column into position. See (fig.1) and (fig.2).



14. Stabilize the side panels with center bands (CB3A) assembly. Fix center band fitting (FCB) to corner column (CCA) with (S2) screws. See Fig. 1 Follow the Fig. 1,2,3,4 & 5.





Fig.1: Use (S2) screws.
Fix (FCB) fitting to (CCA).
Leave it loose.




Fig.2: Use (S1) screws.
Fix (CB3A) to (FCB) and
(CB2A).




Fig.3: Use (S1) screws.
Fix (CB3A) to (CMA)




Fig.4: Fix to (CMA)
with (S1) screw.







Fig.5: Use (S1) Screws.
Fix (CB3A) to (FCB) fitting.




15. Working from inside Continue connecting the 3 side panels (SP↑) and columns (CMA) in sequence along (B22 & B21) base. Use (S1) screws to fix columns to base.



16. Slide corner column (CCA) into side panel (SP↑) pushing the column to the side panel.



17. Working outside use (S1) screws to secure column to bases (B21) and (B1LA).



18. Stabilize the side panels with center bands (CB2A)
& (CB3A). Fix (FCB) fitting to corner column (CCA).
See Fig.1
Follow the Fig. 2, 3, 4 & 5.





Fig.1: Use (S2) screws. Fix (FCB) fitting to (CCA). Leave it loose.




Fig.2: Use (S1) screws. Fix (CB2A) to (FCB) and (CB3A)





Fig.3: Use (S1) screws. Fix (CB3A) to (CMA) columns.




Fig.4: Fix to (CMA) with (S1) screw.







Fig.5: Use (S1) Screws. Fix (CB3A) to (FCB) fitting.



19. Insert the side panel (SP↑) into the groove of column (CCA). Start at the bottom with panel at an angle then push into place.



20. Slide door column (CDLA) into the U-Channel Base (B1LA) on the left side of the door. Line up the pre-drilled holes on (CDLA) Column with pre-drilled holes on U-Channel Base (B1LA). Fix with two (S1) screws from inside. (see blowup detail).



21. To stabilize the front panel attach center band (CB1A). See figures (fig.1) (fig.2).




Fig.1: Use (S1) screws. Fix (CB1A) to fitting (FCB) & (CB3A)





Fig.2: Use (S1) screw. Fix (CB1A) to (CDLA)



Note After completing the center band assembly fully tighten the four center band fittings (FCB) to the corner column (CCA).

22. Fix center band (CB4A) to (CDLA) and Base (B1LA)
See figures (fig.1), (fig.2) and (fig.3).




Fig.1: Use
(S1) screw.
Fix (CB4A) to
(CDLA)




Fig.2: Use
(S1) screw.
Fix (CB4A) to
base (B1LA)






Fig.3: Fix the (EPS) at the end
of (CB1A) & (CB4A).



23. Make sure the door opening between the door columns (CDLA) and (CDRA) is 61 1/4" (1556mm). This will ensure a perfect fit for the doors.






C. Roof Frame

Parts Needed:




- (2) RS1 Roof Structure Left (RS1LA)
- (2) RS1 Roof Structure Right (RS1RA)
- (4) RS2 Roof Structure (RS2A)
- (2) RS3 Roof Structure Long (RS3LA)
- (2) RS3 Roof Structure Short (RS3SA)
- (4) RS4 Roof Structure (RS4A)
- (4) RS5 Roof Structure (RS5A)
- (2) RS6 Roof Structure (RS6A)
- (2) RS7 Roof Structure (RS7A)
- (4) RS8 Roof Structure Support Long (RS8A)
- (4) RS9 Roof Structure Support Short (RS9A)

- (2) RS10 Roof Structure Support (RS10A)
- (2) RS11 Roof Structure Support Short (RS11A)
- (2) RS12 Roof Structure Support Long (RS12A)
- (1) Door Stopper Horizontal (DSH)
- (1) Door Column Fitting Left (FDCL)
- (1) Door Column Fitting Right (FDCR)
- (4) Corner Column Fitting (FCC)
- (7) Middle Column Fitting (FMC)
- (4) 90 Degree Joint (RJ)



1. Insert the middle column fitting (FMC) into top of the middle columns (CMA) square tubing inserts. Fix the column fittings (FMC) to columns (CMA) with (S1) screws from inside the shed.




2. Insert the corner column fittings (FCC) into the corner column's (CCA) square tubing inserts. Fix corner column fittings to (CCA) with (S1) screws from outside of the shed.



3. Insert the door column fittings (FDCL) and (FDCR) left and right into the door columns (CDLA) and (CDRA) square tubing inserts from inside of the shed.




Roof Structure Exploded View




Front roof structure assembly


4. Assemble front roof structure (RS1LA) and (RS1RA) with 2 (S3) screws with nuts.



5. Assemble roof support (RS8A) and (RS9A) to (RS1LA) and (RS1RA) with 6 (S1) screws.




6. Assemble roof structure (RS2A) to (RS8A) and (RS9A) with (S1) screws.




Back roof structure assembly


7. Assemble back roof structure (RS1LA) and (RS1RA) with 2 (S3) screws with nuts.





8. Assemble roof support (RS8A) and (RS9A) to (RS1LA) and (RS1RA) with 8 (S1) screws.



9. Assemble roof structure (RS2A) to (RS8A) and (RS9A) with (S1) screws.






10. Assemble (RS3LA) & (RS3SA) with (S1) screws (2 sets).
See Fig.1.




*Refer Page No. 5 for
Overlapping Method
of (RS3LA) & (RS3SA).*


10a. Insert 90 degree joint (RJ) into the (RS3LA) U-channel
Roof support. Use a hammer to push in. Use (S1) screws to
fix. Repeat on other end of (RS3SA). See fig.2 & fig.3




11. Assemble the roof structure (RS5A) into
(RS6A) with 6 (S3) screws with nuts (2 sets).




12. Assemble the roof structure (RS5A) into
(RS7A) with 6 (S3) screws with nuts (2 sets).





13. Lift the assembled front roof structure into position on top of door columns. Line up pre-drilled holes with door column fittings (FDCL) & (FDCR). Use (S1) screws to fix front roof structure to the door columns with left and right door column fittings.



14. Fix the door stopper horizontal (DSH) to the front roof structure from inside with 6 (S1) screws. Position the latch hole to face down.



15. Lift the assembled back roof structure into position on top of middle columns (CMA). Line up pre-drilled holes with middle column fittings (FMC). Use (S1) screws to fix back roof structure to (FMC).



Note Make sure in (RS1LA) & (RS1RA) front and back assembly, the (RS2A) roof structure position towards inside the shed as shown in Fig.1 & Fig.2





Fig.1







Fig.2

16. Insert the roof supports (RS3LA) & (RS3SA) assembly into the U-channel of roof structures (RS1LA) & (RS1RA). See Fig.1.

Follow (fig.2) & (fig.3)



After assembly make sure (RS3LA) & (RS3SA) roof structure's U-Channel is positioned down.



Notice the U-channel up position on roof structures (RS1LA) & (RS1RA).





fig.1




fig.2

Secure (RJ) 90 degree joint to (RS1LA) & (RS1RA) with (S1) screws on top of the four corner columns (CCA).
Secure (RJ) with (FCC) using (S2) screw on all the four corner columns.







fig.3

Fix (RS2A) to 90 degree joint (RJ) through (RS3LA) & (RS3SA) with (S1) screw.

16a. Fix (RS3LA) & (RS3SA) assembly to (FMC) middle column fitting with (S1) screws.



17. Lift the assembled roof supports (RS5A) & (RS6A) into position on roof supports (RS8A) at the left side of the shed.
Use (S1) screws to fix (RS5A) & (RS6A) to (RS8A); and (RS2A) to (RS5A) & (RS6A).
See Fig.1 & Fig.2



18. Lift the assembled roof supports (RS5A) & (RS7A) into position on roof supports (RS8A) at the right side of the shed.
Use (S1) screws to fix (RS5A) & (RS7A) to (RS8A); and (RS2A) to (RS5A) & (RS7A).
See Fig.1 & Fig.2





fig.1







fig.2

19. Attach (RS10A) and (RS11A) to roof structures (RS5A), (RS6A) & (RS7A) using (S1) screws. See (fig.1), (fig.2) and (fig.3).



Note Make sure hole in (RS10A) face outward.





fig.1




fig.2





fig.3



20. Lift the assembled roof supports (RS5A) & (RS6A) into position on roof supports (RS9A) at the left side of the shed.
Use (S1) screws to fix (RS5A) & (RS6A) to (RS9A);
and (RS2A) to (RS5A) & (RS6A).
See Fig.1 & Fig.2

21. Lift the assembled roof supports (RS5A) & (RS7A) into position on roof supports (RS9A) at the right side of the shed.
Use (S1) screws to fix (RS5A) & (RS7A) to (RS9A);
and (RS2A) to (RS5A) & (RS7A).
See Fig.1 & Fig.2





fig.1




fig.2

22. Attach the roof structures (RS4A) 4 nos. to (RS5A), (RS6A) assembly and (RS5A), (RS7A) assembly and (RS3LA), (RS3SA) with (S1) screws. See (fig.1) (fig.2) (fig.3) and (fig.4)






fig.1




fig.2




fig.3





fig.4



23. Attach the roof structures (RS12A) with (RS5A) to (RS5A) and (RS6A) to (RS7A) with (S1) screws. See (fig.1) and (fig.2)





fig.1





fig.2




D. Roof panels



Parts Needed:

- (6) Roof Panels (RP↑)
- (2) Facia Panel Left (FPL)
- (2) Facia Panel Right (FPR)
- (3) Ridge Cover Small (RRS)
- (80) Roof Plug Washer (PWS)
- (80) Roof Plug (PPG)
- (80) Roof Pin (PIN)
- (12) Sagging Support (RS14A)






1. Place facia panel (FPR) to front roof structure right side.



2. First put the roof plug washer on the roof plug. Locate the holes in the facia panel through roof structure and fix with roof plugs w/washers. Use a hammer (rubber mallet) to drive in roof pin. See fig. 1, 2 & 3 for details. Place facia panel left (FPL) to the front roof structure left side. Make sure (FPL) overlaps on (FPR). Repeat action to fix facia panels on backside. See Fig. 4, 5 & 6.




TIP First insert all roof plugs with washers to the panels (left & right) then drive in the roof pins.



3. Start attaching the roof panels from (FPL) corner side by sliding the roof panel (RP↑) to roof structure. Locate the hole positions of the roof panel and roof structure. Fix roof plugs with washers. Use a hammer to drive in roof pins. See figures 1 thru 6.


4. Attaching the ridge cover (RRS) on top of the roof panels (RP↑) start from the front side of the shed. See Fig. 7 Fig. 8 Fig. 9











Note Use a screw driver to align the holes.
Insert roof plugs into roof panels only as indicated.

KEY
P Roof Plugs


Note Do not insert Plugs at this point.





5. Insert the sagging support (RS14A) from inside the shed by sliding it between roof support (RS5) and roof panel until it reaches (RS3) roof support for each panel. See figures.

6. Insert the sagging support (RS14A) from inside the shed by sliding it between roof support (RS5) and roof panel until it touches the other roof support. See figures.



E. Doors

Parts Needed:



- (1) Door Left
- (1) Door Right

1. Attach the doors left and right (see fig.1) with Loose pin hinges on door columns (CDLA) and (CDRA).





Note: To prevent water leakage it is important that these instructions are followed.

1. After completing the assembly apply silicone around the perimeter of the base U-channel. Seal the corners, joints and base of door column also.



2. After completing the panel assembly, apply silicone around the roof plugs. This is optional and should be done for heavy rain areas if needed.



F. Optional Ventilation Kit

ACCESSORIES

CODE	DESCRIPTION	QTY
VC	VENTILATION COVER	2
VCP	VENTILATION COVER PIN	4

TOOLS YOU WILL NEED

Power Drill
Dia 5/32" (4.2mm) drill bit
Dia 1/2" (12.5mm) drill bit

Optional ventilation kits can be installed on any of the wall panels. However, we recomend mounting them on the top of the shed's back wall.

1. Place the ventilation cover (VC) as shown in fig.1. Using a pencil, mark the two side hole locations.
2. On the marked hole locations, drill out two holes using dia. 5/32" (4.2mm) drill bit as shown in fig.2. These holes will be used to attach the ventilaion cover with the ventilation cover pins (VCP).
3. Use a dia. 1/2" (12.5mm) drill bit to drill out as many holes as desired behind the ventilation cover mounting area as in fig.3.
4. Attach the ventillation cover (VC) with the ventilation cover pin (VCP) as in fig.4.
5. Repeat the same to fix the second ventilation cover.





fig.1

Outside




fig.2




fig.3




fig.4



High wind area installation instructions

Note: To ensure that your shed withstands high winds, you will need the following reinforcement.



Parts needed:

CODE	DESCRIPTION	QTY
S4	DIA. 4.2 x 16mm. (5/32" x 5/8") SHEET METAL SCREW	48 (not included with shed)
S5	M6 x 40mm. (1/4" x 1 1/2") Anchor bolt with nut	32 (not included with shed)

1. Shed or shed foundation should be placed on concrete footing by use of anchor bolt and nut. Using a carpenters square, line up corners. Align U-Channel base, mark the concrete at the holes in the base and drill concrete with 1/2" (dia. 12.5mm) concrete bit to accept anchor bolts to a 1 3/4" (44mm) depth. Replace base and secure with 1/4" x 1 1/2" (M6 x 40mm) anchor bolts. See fig.



2. Attach each side panel (SP↑) on the bottom to the U-channel base. Using a dia. 3mm (1/8") drill with a power drill, make two equal distance holes on the U-channel base through the side panel. Drive a self tapping screw (S4) through the base U-channel to the side panel. Repeat this for every side panel. See blowup.





32